


SS-125 FLASHHEAD COMPONENT LAYOUT



Item #	Description	Part Number
A1	High Voltage Supply Board	*277-3261
A2	Trigger Control Board	*277-3262
A3	Fault Monitor Board	*277-3263
C1	Capacitor, 1uF, 1700V	*77-4220
C2	Capacitor, 12.5uF, 2500V	*77-4108
C3	Capacitor, 110uF, 2500V	*77-4133-001
C4	Capacitor, 3uF, 2500V	*77-3311
DB1	Diode Block	*277-3342-6
DS1	Interlock Assembly (w/ S1-S3)	*77-3323
E1	Stainless Steel Enclosure, SS-125	*77-3296-02
F1	Fuse, SB, 3.2A – 480V System	*77-2041
F1	Fuse, SB, 6A – 240V System	*77-1167
F1	Fuse, SB, 10A – 120V System	*77-2040
F2-F5	Fuse, SB, 1A, 3AG	*77-2365
FT	Flashtube Assembly	*77-3295
FTS	Flashtube Assembly with sockets	*77-3295S
K1	Interlock Relay	*77-2878
K2-K4	Mode Relays	*77-2013
LA	Surge Arrestor	*77-4139
MB	Mother Board	*277-3264
R1-R6	Resistor Block Assembly	*277-3546
RA	Reflector Assembly	*277-3898
S1	Interlock Switch	*77-2644
S2	Remote/Local Switch	*77-2668
S3	Mode Switch (Day, Twilight, Night)	*77-2667
T1	Input Transformer, 60Hz	*77-3890
T1	Input Transformer, 50Hz	*77-4244
T1-SB	Input Transformer Voltage Selector Block, 120V	*77-3319
T1-SB	Input Transformer Voltage Selector Block, 240V	*77-3321
T1-SB	Input Transformer Voltage Selector Block, 480V	*77-3322
T2	Trigger Transformer Assembly (w/terminals)	*277-3324
WH	Wire Harness Assembly	*77-3355A